Class 11



Lesson Plan

- 3 phase power and transformers any questions?
- Project update and next steps

- Next Saturday Session Roseville campus, 8a
 - Need load equipment (trucks are welcome)

Project Progress

- Structural mounts installed
- Attachment points installed
- Rails are installed
- Rails are bonded
- Modules mounted
- Combiner box installed
- Inverter and disconnect installed

Need to

- Wire modules as 3 x 11 array and land at the combiner box
- Lay conduit from combiner box to inverter
- Pull wire

Project Open Issues

- Structural still need be cross-braced
- Need determine where and how we will mount BOS
- (What is the BOS)
- How do we ground the system?
- How do we connect to AC system?

Need to

- Determine conductor type, size, length, color
- Determine conduit type, size, length
- Determine fuse and breaker requirements
- Determine conduit run

5

Consider an array of 33 Sharp NT175U1 modules, three parallel strings of 11. Use the NEC tables to answer the following questions. (Isc = 5.40A)

1. What is the Continuous Current for each string of the array?

$$5.4A * 1.25 = 6.75A$$

2.Each string is connected through an fused combiner box. What is the over current device rating for each string?

3. What is the required ampacity at 30C for each string?

$$5.4A * 1.25 * 1.25 = 8.44A$$

4.We want to use USE02 conductors in these circuits. What is the temperature derating factor if the expected temperature is 135F? What is the conduit fill derating factor?

Conduit Derate = 1.0

- 5. Using NEC tables, select a conductor size. I chose 14AWG USE-2
- 6.Derate the conductor you selected based on the derating factors above. What is the derated amapacity?

 35A * 0.71 * 1 = 24.8A
- 7.Is the derated ampacity greater than the Continous Current ? If yes, move ahead, if no, repeat steps 5,6,7 **Yes**
- 8. Is the derated ampacity greater than the over current protection device rating? If yes, move ahead, if no, repeat steps 5,6,7,8.

9. The combiner box terminals are rated at 75C. What is the ampacity at 30C of the combiner box terminals?

The 14AWG USE-2 conductor ampacity at 75C = 30A

- 10. Are the combiner box terminals acceptable for this application?
 Yes
- 11. The combiner box is outside but not in direct sunlight. The expected temperature is 40C. Is this acceptable?

Yes, but if temperature is greater than 40C then we need to refer to the manufacture's specifications to determine if we can use.

Consider the same array of 33 Sharp NT175U1 modules (Isc = 5.40A) and the circuit between the combiner box and the inverter disconnect switch

1. What is the Continuous Current for the circuit out of the combiner box?

2. What is the over current device rating for the circuit?

3. What is the required ampacity at 30C for each string?

$$5.4A * 3 * 1.25 * 1.25 = 25.3A$$

4.We want to use THWN-2 conductors in conduit. What is the temperature derating factor if the expected temperature is 140F? What is the conduit fill derating factor?

Temperature Derate = 0.71

Conduit Derate = 1.0

- 5. Using NEC tables, select a conductor size.
- I chose 10AWG THWN-2
- 6.Derate the conductor you selected based on the derating factors above. What is the derated amapacity? 40A * 0.71 * 1.0 = 28.4A
- 7.Is the derated ampacity greater than the Continous Current ? If yes, move ahead, if no, repeat steps 5,6,7

 Yes
- 8. Is the derated ampacity greater than the over current protection device rating? If yes, move ahead, if no, repeat steps 5,6,7,8.

No, pick next larger conductor – 8AWG

9. The disconnect switch terminals are rated at 75C not 90C. What is the ampacity at 30C of the inverter terminals?

The 8AWG THWN-2 conductor ampacity at 75C = 50A

10. Are the terminals acceptable for this application?

Yes

11. The disconnect switch is not in direct sunlight. The expected max temperature is 40C. Is this acceptable?

Yes

Consider the same system of 33 Sharp NT175U1 modules (Isc = 5.40A). The modules are connected to a SMA Sunny Boy 6000US with an output continous current rating of 29A.AC.

- 1.What is the Continuous Current for the circuit between the inverter and AC disconnect?

 29A
- 2. What is the over current device rating for the circuit?

29A* 1.25 = 36.25A, go to next higher circuit reaker value – 40Amp

3. What is the required ampacity at 30C for each string?

4.We want to use THWN conductors in conduit. What is the temperature derating factor if the expected temperature is 110F? What is the conduit fill derating factor if there are 3 current carrying conductors in the conduit?

Temperature Derate = 0.82

Conduit Derate = 1.0

- 5. Using NEC tables, select a conductor size. I chose 8AWG THWN
- 6.Derate the conductor you selected based on the derating factors above. What is the derated amapacity?

 50A * 0.82 * 1.0 = 41A
- 7.Is the derated ampacity greater than the Continous Current ? If yes, move ahead, if no, repeat steps 5,6,7 **Yes**
- 8. Is the derated ampacity greater than the over current protection device rating? If yes, move ahead, if no, repeat steps 5,6,7,8.

 Yes

9. The disconnect switch terminals are rated at 75C not 90C. What is the ampacity at 30C of the inverter terminals?

The 8AWG THWN conductor ampacity = 50A (same temp rating as conductor)

10. Are the terminals acceptable for this application?

Yes

11. The disconnect switch in direct sunlight. The expected temperature is 45C. Is this acceptable?

Yes

Conduit Calculation

• NEC Chapter 9, Table 1: Percent of Cross Section of Conduit

Number of Conductors	All Conductor Types	
1	53	
2.	31	
Over 2	40	

• NEC Chapter 9, Table 4: Cross sectional area of EMT Conduit

Metric Designator	Trade Size	Nominal Internal Diameter		Total Area 100%		2 Wires 31%		Over 2 Wires 40%		1 Wire 53%		60%	
		mm	in.	mm²	in.2	mm ²	in.2	mm ²	in.2	mm ²	in.2	mm ²	in.2
16	1/2	15.8	0.622	196	0.304	61	0.094	78	0.122	104	0.161	118	0.182
21	3/4	20.9	0.824	343	0.533	106	0.165	137	0.213	182	0.283	206	0.320
27	1	26.6	1.049	556	0.864	172	0.268	222	0.346	295	0.458	333	0.519
35	11/4	35.1	1.380	968	1.496	300	0.464	387	0.598	513	0.793	581	0.897
41	11/2	40.9	1.610	1314	2.036	407	0.631	526	0.814	696	1.079	788	1.221
53	2	52.5	2.067	2165	3.356	671	1.040	866	1.342	1147	1.778	1299	2.013
63	21/2	69.4	2.731	3783	5.858	1173	1.816	1513	2.343	2005	3.105	2270	3.515
78	3	85.2	3.356	5701	8.846	1767	2.742	2280	3.538	3022	4.688	3421	5.307
91	31/2	97.4	3.834	7451	11.545	2310	3.579	2980	4.618	3949	6.119	4471	6.927
103	4	110.1	4.334	9521	14.753	2951	4.573	3808	5.901	5046	7.819	5712	8.852

Article 358 - Flectrical Metallic Tubing (FMT)

Conduit Calculation

NEC Chapter 9, Table 5: Dimensions of insulated wires

	Size (AWG or kcmil)	Approxi		Approximate Area	
Туре		mm	ín.	mm²	in. ²
THHN,	14	2.819	0.111	6.258	0.0097
THWN,	12	3.302	0.130	8.581	0.0133
THWN-2	10	4.166	0.164	13.61	0.0211
	8	5.486	0.216	23.61	0.0366
	6	6.452	0.254	32.71	0.050
	4	8.230	0.324	53.16	0.0824
	3	8.941	0.352	62.77	0.0973
	2	9.754	0.384	74.71	0.1158
	1	11.33	0.446	100.8	0.156
	1/0	12.34	0.486	119.7	0.185
	2/0	13.51	0.532	143.4	0.222
	3/0	14.83	0.584	172.8	0.267
	4/0	16.31	0.642	208.8	0.323
	250	18.06	0.711	256.1	0.397
	300	19.46	0.766	297.3	0.460

How many 10AWG THWN-2 conductors can be run through ¾ inch EMT?

0.213 / 0.0211 = 10 conductors

DC Design Requirements

Combiner to Inverter

• Determine conductor type, size, length, color

The 8AWG THWN-2 150ft Black, White, Green (or bare)

Determine conduit type, size, length

EMT ½ inch 200ft

Determine fuse and breaker requirements


10amp fuses in the combiner box

30amp fuse in the DC disconnect switch


What is the expected voltage drop in the DC circuits?


.778 * 300/1000 * 30A = 7.002V / 488.4VOC = .014 (1.43%)

- How do we design a 3-phase PV system
- Use multiple single phase inverters











Energy Instructor www.energyinstructor.info






Main Building Distribution Panel

Inverter data sheet

	SB 5000US	SB 6000US	SB 7000US
Recommended Maximum PV Power (Module STC)	6250 W	7500 W	8750 W
DC Maximum Voltage	600 V	600 V	600 V
Peak Power Tracking Voltage	250-480 V	250-480 V	250-480 V
DC Maximum Input Current	21 A	25 A	30 A
Number of Fused String Inputs	3 (inverter), 4 x 20 A (DC disconnect)	3 (inverter), 4 x 20 A (DC disconnect)	3 (inverter), 4 x 20 A (DC disconnect)
PV Start Voltage	300 V	300 V	300 V
AC Nominal Power	5000 W	6000 W	7000 W
AC Maximum Output Power	5000 W	6000 W	7000 W
AC Maximum Output Current (@ 208, 240, 277 V)	24 A, 21 A, 18 A	29 A, 25 A, 22 A	34 A, 29 A, 25 A
AC Nominal Voltage Range	183 - 229 V @ 208 V 211 - 264 V @ 240 V 244 - 305 V @ 277 V	183 - 229 V @ 208 V 211 - 264 V @ 240 V 244 - 305 V @ 277 V	183 - 229 V @ 208 V 211 - 264 V @ 240 V 244 - 305 V @ 277 V
AC Frequency: nominal / range	60 Hz / 59.3 - 60.5 Hz	60 Hz / 59.3 - 60.5 Hz	60 Hz / 59.3 - 60.5 Hz
Power Factor (Nominal)	0.99	0.99	0.99
Peak Inverter Efficiency	96.8%	97.0%	97.1%
CEC Weighted Efficiency	95.5% @ 208 V 95.5% @ 240 V 95.5% @ 277 V	95.5% @ 208 V 95.5% @ 240 V 96.0% @ 277 V	95.5% @ 208 V 96.0% @ 240 V 96.0% @ 277 V
Dimensions: W x H x D in inches	18.4 × 24.1 × 9.5	18.4 × 24.1 × 9.5	18.4 × 24.1 × 9.5
Weight / Shipping Weight	141 lbs / 148 lbs	141 lbs / 148 lbs	141 lbs / 148 lbs
Ambient Temperature Range	−13 to 113 °F	−13 to 113 °F	−13 to 113 °F
Power consumption at night	0.1 W	0.1 W	0.1 W

- How do we design a 3-phase PV system
- Use multiple single phase inverters



- What is the OCPD rating for inverter output?
 (max AC output of SB6000US at 208V = 29A)
 - 29A * 1.25 = 36.25A next size = 40A
- What is the OCPD rating of each phase?
- What is the OCPD for the 3 phase subpanel? $29A * \sqrt{3} = 50.2A * 1.25 = 62.8A$ next size = 70A

AC Design Requirements

Inverter to Solar Subpanel

Determine conductor type, size, length, color

The 8AWG THWN-2 25ft Red, Black, White, Green (or bare)

Determine conduit type, size, length

EMT $\frac{1}{2}$ inch 25ft

Determine fuse and breaker requirements
 40amp breaker in the solar subpanel

What is the expected voltage drop in the AC circuits?

.778 * 50/1000 * 40A = 1.556V / 208V = .0075 (.75%)

AC Design Requirements

Solar Subpanel to Building Subpanel

Determine conductor type, size, length, color

The 4AWG THWN-2 75ft Red, Black, Blue, White, Green (or bare)

Determine conduit type, size, length

Rigid or PVC 1 1/4 inch 75ft

Determine fuse and breaker requirements

70amp breaker in the solar subpanel

What is the expected voltage drop in the AC circuits?

.308 * 150/1000 * 70A = 3.234V / 208V = .0155 (1.55%)

AC Design Requirements

Need to

Determine conductor type, size, length, color

The 8AWG THWN-2 10ft Black, White, Red, Green (or bare)
The 4AWG THWN-2 75ft Black, White, Red, Blue, Green (or bare)

Determine conduit type, size, length
 EMT ½ inch 20ft
 Rigid PVC Sch40 1 1/4" inch 10ft

Determine fuse and breaker requirements

3x 2 pole 40amp circuit breakers in the inverter sub panel Need a 3 phase MLO load center, 125A, 12 slot, NEMA 3R 1x 3 pole 70amp circuit breaker in the supply panel