Conduit



Conduit



Conduit comes in various configuration

- EMT Electrical Metallic Tubing
 - Thin wall conduit
 - 40% thinner than rigid
 - Lighter, easier to bend, & no threading
- RMC Rigid Metal Conduit
 - Heavy duty
 - Requires threading-like plumbing
 - Generally used for service entrance risers.
- IMC Intermediate Metal Conduit
 - Between RMC and EMT
 - Can be threaded
- PVC Polyvinylchloride
 - Cheaper alternative
 - High coefficient of thermal expansion
- FMC Flexible Metal Conduit
- LFMC Liquidtight Flexible Metal Conduit
- FMT, LFNMC, ENT

Conduit comes in various sizes

- ½", ¾", 1", 1-¼", 1-½", 2", 2-½", 3", 4"
- For the "same size" conduit- EMT, IMC and RMC may have a different inside area

Per NEC

- Min size = $\frac{1}{2}$ inch
- Permitted usages vary for each type
- Article 358: EMT

Support requirements (RMC, EMT, IMC)


- Securely fastened every 3m (10ft)
- Within 0.9m (3ft) from every junction box, outlet, transition, direction change
- Should follow horizontal and vertical lines, smooth transitions
- No more than 4 quarter bends between pull points

Energy Instructor www.energyinstructor.info


Conduit Discussion




- electrical boxes using compression, indenter, or screw set connectors.
 - Compression firmly secures the conduit by utilizing a nut that compresses a tapered metal ring into the conduit.
 - Can be reused several times
 - Indenter Use of a special tool to make an indention (swaging)
 - Set Screw used to connect two runs of conduit together and maintain a smooth inside run.



COMPRESSION



INDENTER



SET SCREW

Number of Conductors	All Conductor Types
1	53
2.	31
Over 2	40

NEC Chapter 9, Table 4: Cross sectional area of EMT Conduit

Article 358 — Electrical Meta	allic Tubing (EMT)
-------------------------------	--------------------

Metric Designator		Nominal Internal Diameter		Total Area 100%		2 Wires 31%		Over 2 Wires 40%		1 Wire 53%		60%	
	Trade Size	mm	in.	mm ²	in.2	mm²	in.2	mm ²	in. ²	mm ²	in.2	mm ²	in.2
16	1/2	15.8	0.622	196	0.304	61	0.094	78	0.122	104	0.161	118	0.182
21	3/4	20.9	0.824	343	0.533	106	0.165	137	0.213	182	0.283	206	0.320
27	1	26.6	1.049	556	0.864	172	0.268	222	0.346	295	0.458	333	0.519
35	11/4	35.1	1.380	968	1.496	300	0.464	387	0.598	513	0.793	581	0.897
41	11/2	40.9	1.610	1314	2.036	407	0.631	526	0.814	696	1.079	788	1.221
53	2	52.5	2.067	2165	3.356	671	1.040	866	1.342	1147	1.778	1299	2.013
63	21/2	69.4	2.731	3783	5.858	1173	1.816	1513	2.343	2005	3.105	2270	3.515
78	3	85.2	3.356	5701	8.846	1767	2.742	2280	3.538	3022	4.688	3421	5.307
91	31/2	97.4	3.834	7451	11.545	2310	3.579	2980	4.618	3949	6.119	4471	6.927
103	4	110.1	4.334	9521	14.753	2951	4.573	3808	5.901	5046	7.819	5712	8.852

NEC Chapter 9, Table 5: Dimensions of insulated wires

	Size (AWG	Approxi Diame		Approximate Area		
Туре	or kcmil)	mm	ín.	mm²	in.2	
THHN.	14	2.819	0.111	6.258	0.0097	
THWN,	12	3.302	0.130	8.581	0.0133	
THWN-2	10	4.166	0.164	13.61	0.0211	
	8	5.486	0.216	23.61	0.0366	
	6	6.452	0.254	32.71	0.0507	
	4	8.230	0.324	53.16	0.0824	
	3	8.941	0.352	62.77	0.0973	
	2	9.754	0.384	74.71	0.1158	
	1	11.33	0.446	100.8	0.1562	
	1/0	12.34	0.486	119.7	0.185	
	2/0	13.51	0.532	143.4	0.222	
	3/0	14.83	0.584	172.8	0.2679	
	4/0	16.31	0.642	208.8	in.2 0.009 0.013 0.021 0.036 0.050 0.082 0.097 0.115 0.156 0.222 0.267 0.323	
	250	18.06	0.711	256.1	0.397	
	300	19.46	0.766	297.3	0.460	

How many 10AWG THWN-2 conductors can be run through ¾ inch EMT?

0.213 / 0.0211 = 10 conductors





opening

Dog leg – Mistake in bends when legs do not line up¹⁰



- Take-up is the length of pipe to remove from desired height to make the a stub
 - 5 inch for ½ inch bender
 - 6 inch for ¾ inch bender
 - 8 inch for 1 inch bender
- Offset chart is used to calculated proper lengths for various bends

Degree of Bend

- 30 degree = 2X length
- 30 degree = $\frac{1}{4}$ X shrink


	22-1/2°			3	0°	Δ	·5°	60°		
		22	172		0	7	3	00		
	2"	5-1/4"	3/8"							
	3"	7-3/4"	9/16"	6"	3/4"					
	4"	10-1/2"	3/4"	8"	1"					
Offset Depth Inches	5″	13"	15/16"	10"	1-1/4"	7"	1-7/8"			
	6"	15-1/2"	1-1/8"	12"	1-1/2"	8-1/2"	2-1/4"	7-1/4"	3"	
	7"	18-1/4"	1-5/16"	14"	1-3/4"	9-3/4"	2-5/8"	8-3/8"	3-1/2"	
	8"	20-3/4"	1-1/2"	16"	2"	11-1/4"	3"	9-5/8"	4"	
	9"	23-1/2"	1-3/4"	18"	2-1/4"	12-1/2"	3-3/8"	10-7/8"	4-1/2"	
	10"	26"	1-7/8"	20"	2-1/2"	14"	3-3/4"	12"	5"	

11



Conduit Videos

Conduit Bend: 90 degree stub and back to back




Video Link: **Haywood Community College 90 degree stub up conduit bend into a back to back**

http://www.youtube.com/watch?v=Ws1QifXhh4U&feature=player_embedded



Conduit Videos

Conduit Bend: 30 offset



Video Link: **Haywood Community College Conduit Bending off set bend** http://www.youtube.com/watch?v=8zY91dJYFRk&feature=player_embedded



Conduit Exercise

Every get a 10ft piece of ½ in EMT

- Bend a 12" stub in
- Bend a 24" back to back from the first stub
- Cut and file the tube so that you have two 12" back to back stubs

Using remaining piece of ½ in EMT

• Bend a 30 degree 5" offset